

Series 900 Angled Door Shelf Track and Support Arm:

- Shelf Track screws to the front of a shelf. There is also a stop (shown in image below) to cover the cut end of the track if required. After the track has been screwed to the shelf, there is a cover strip for hiding the screws (not shown in image below)



- See below for general image of the support arms fixed to the back of the door and how they run in the shelf track



- Please note the orientation of the dog leg on the plate (shown below). For Series 900 it is positioned so the plate is further away from the back of the door, so that the 4 screw tips are away from the glass (this is different to the image above which is for Series 700)
- Please also note that the left edge of the plate is positioned close to the left edge of the door. The 2 screws go through the door frame into the empty cavity away from the glass.
- If in doubt please call on 0208 123 8686 or email info@slidingwardrobeworld.com

